



SILVER SPORT
Transmissions

AMC AMX JAVELIN 1968-69

PEDAL CONNECTION INSTRUCTIONS

The material herein is the intellectual property of Silver Sport Transmissions ("SST") and is to be used by SST customers or their authorized installers for the sole purpose of installing SST-supplied transmissions and related parts. Under no circumstances shall the manual or any portion thereof be copied, duplicated, distributed or incorporated in any written or printed document without the express written approval of Silver Sport Transmissions.

SYSTEM DESCRIPTION:

These instructions cover ONLY the installation of pedal assembly for the AMC AMX Javelin 1968-69.

Refer to **MAG-00402 (FTE style) or MAG-00403 (RAM style) HYDRAULIC KIT INSTRUCTIONS FOR GM TKO, T56, MAGNUM, AND LGT700** for complete instructions on installation of the hydraulic concentric slave cylinder (CSC) and hydraulic release

PEDAL ATTACHMENT

1. Attach pedal bracket using bolts provided. The bracket will attach to the pedal using one of the original holes and the pedal stop hardware.

